

Installation Instructions

- Access Panels

Framed (part no. AP1522)

1. Prior to cutting ensure area is clear of plumbing and electrical wires before proceeding
2. Use the product label supplied with the panel as a 151 x 227mm template for cutting the correct sized hole
3. Carefully make the hole in the wall or ceiling with an appropriate saw or tool for the material being cut
4. insert the frame and glue into place using an appropriate adhesive suitable for the plastic of the panel and the material of the surface being used



Unframed Spring Loaded (part nos. AP2020 and AP3535)

1. Prior to cutting ensure area is clear of plumbing and electrical wires before proceeding
2. Use the product label supplied with the panel as a template for cutting the correct sized hole
3. Carefully make the hole in the wall or ceiling with an appropriate saw or tool for the material being cut
4. Clip flaps up on both sides of the panel
5. Align panel inside bottom of opening, then push panel into wall. Flaps will click and hold panel in place
6. To remove the panel, pull on the opposite sides of the flap

