

Installation Instructions

– Metal Eave Vents

1. Select a location between studs on eaves that is clear of electric, plumbing and other obstructions
2. Mark out and cut a 370 x 170mm (max) rectangular hole in the eave using an appropriate saw
3. Secure the metal vent with 15mm x 8g metal button head screws (not supplied)



Note: Screws, saw, pencil and screwdriver can be used for installation.