

Installation Instructions – Snap In Eave Vents

1. Ensure proposed position on eave is clear of wiring, plumbing or other obstructions
2. Use the provided template to mark our hole to be cut
3. Cut hole using appropriate saw
4. Open up the 4 clip so that the larger side is vertical and can catch the underside of the eave
5. Push the vent up from underneath into hole
6. Ensure clips fasten on the eave and no gaps are present
7. Attached ducting to the neck of the vent using worm clamps and/or duct tape

