

# Installation Instructions

## – Caravan/Cupboard Vents

1. Select a location between studs on eaves that is clear of electric, plumbing and other obstructions
2. Mark out and cut:
  - a. for the 300 x 300mm size, a max 265 x 265mm hole
  - b. for the 300 x 150mm size, a max 265 x 115mm hole
  - c. for the 225 x 150mm size, a max 185 x 115mm hole
  - d. for the 150 x 100mm size, a max 115 x 70mm hole
  - e. for the 100 x 75mm size, a max 70 x 45mm hole
3. Secure the metal vent with 15mm x 8g metal button head screws (not supplied) or appropriate rivets

Note: Screws, saw, pencil and screwdriver can be used for installation.

