

Installation Instructions

– Duct Joiners & Adapters

1. Slide an appropriately sized steel worm clamp over both lengths of the semi-rigid or foil ducting
2. Insert the joiner/adapter into the inside of the ducting
3. Using duct tape, secure the ducting to the joiner/adapter
4. Put the steel worm drive clamp into position and tighten with a Philips head screw driver
5. Repeat steps 2 - 4 on the other end of the joiner/adapter



Duct Joiner

Steel Worm Clamp



Duct Adapter