

# Y Piece Connectors



## Instructions

- + Ensure the Y piece connector is dry and clear of contaminants
- + Put the ducting over the openings and secure with duct tape and/or steel worm clamps
- + If using clamps, ensure that at least 10mm of ducting extends past the clamp
- + If using duct tape, use a minimum of 3 overlapping wraps around the neck
- + Ensure an air tight seal is completed

**Note:** If installation requires compliance with AS4254, review the installation requirements under section 2.5.