

Clip Seam Pipe



Instructions

- + Clip the seam on the pipe together (easiest done on a flat surface)
- + Attach the cowl to the non-crimped end via rivets or silicone adhesive (or both) as appropriate
- + Slide the ducting over the crimped end of the pipe
- + Secure ducting to the pipe with steel worm clamps and/or duct tape
- + If you need an additional length, 2 pipes can be joined using duct tape, clamps or a sheath. (check appropriate regulations depending on your application)

Note 1: For the best fit we recommend using both worm clamps and duct tape. Duct tape on its own can lose adhesion over time

Note 2: Pipe is usually inserted via an appropriate roof flashing for your roof

Partner Pacific Pty Ltd.

5 Amay Crescent, Ferntree Gully, Vic 3156

Phone: 03 9758 7844

Email: enquiries@partnerpacific.com